 <p>15 rue des Frères Lumière – BP 136 78374 PLAISIR FRANCE Tél : 01.30.80.81.98 Fax : 01.30.80.81.99 WEB : www.sherwinbabbco.eu E-MAIL : sherwinbabbco@orange.fr</p>	<p>TECHNICAL</p> <p>DATA SHEET</p>	<p>Ref : TDS/ B102A</p> <p>Page : 1/2</p> <p>Rev : 1 Date : 10/2011</p>
--	--	---

STRIPPABLE WHITE CONTRAST PAINT FOR MAGNETIC TESTING B102A “PELLICAL”



MANUFACTURER: Babb Co (FR)

DESCRIPTION / APPLICATION(S):

White strippable contrast paint, **very easy to take off by stripping**; fast drying, high opacity white paint. Improves performance of any black or red magnetic detecting medium.

Companion products: black magnetic ink: B103C, KP42A, WCB42, BabbCoSafe 820A, BabbCoSafe 850A

SPECIFICATION(S) / STANDARD(S) :

- Conforms to code(s) : ASME, RCC-M
standard(s): ISO 9934-2
- This product complies with REACH regulation.

PHYSICO-CHEMICAL PROPERTIES:


- Aspect : white liquid
- Odor : characteristic
- Compatible with all ferromagnetic metals.

PACKAGING / TRANSPORT / STORAGE :

.Packaging : 500mL spraycan
10L can

.Transport / Handling: Refer to Material Safety Data Sheet (MSDS).

.Storage / Shelf life: Keep away from moisture
Temperature range: 0°C à 50°C
Keep packaging closed after taking out some of the product.

 <p>15 rue des Frères Lumière – BP 136 78374 PLAISIR FRANCE Tél : 01.30.80.81.98 Fax : 01.30.80.81.99 WEB : www.sherwinbabbco.eu E-MAIL : sherwinbabbco@orange.fr</p>	<p>TECHNICAL</p> <p>DATA SHEET</p>	<p>Ref : TDS/ B102A</p> <p>Page : 2/2</p> <p>Rev : 1 Date : 10/2011</p>
--	--	---

Spraycan / can : 24 months

INSTRUCTIONS:

If necessary remove scale, paint residue, oxide, etc...

Degrease using degreaser N 120, DR-62, BabbCoSafe 105 and cleaning rags or preimpregnated N 120 swabs if necessary.

Strongly shake **B102A "Pellical"** spraycan, then, from a distance of **30 cm**, firmly push nozzle while keeping spraycan upside.

Spray a thin, uniform coat of **B102A "Pellical"** (if possible only one layer). The layer is generally 30µm thick.

A thin layer is enough. Too a thick coat leads to coat defects ("**orange skin**") and decreases inspection sensitivity.

B102A "Pellical" is not soluble in water or in currently used hydrocarbon-based magnetic inks.

After inspection, **B102A "Pellical"** layer may be **stripped as easily as, say, wallpaper** when used on smooth surfaces. It can also be brushed on too rough surfaces.

HEALTH AND SAFETY: Refer to Material Safety Data Sheet (MSDS).

The information given herein is given in good faith to our customers for the sole purpose of assisting them in the use of the products. The document contains no formal or implicit guarantee regarding its use.

Babb Co cannot be held responsible for damages of any nature resulting from information provided in this document. In addition, none of the information which the document contains should be interpreted as a recommendation for the use of the products which would infringe the protected rights of industrial property.