



15 rue des Frères Lumière – BP 136
78374 PLAISIR
FRANCE

Tél : 01.30.80.81.98

Fax : 01.30.80.81.99

WEB : www.babbco.fr

E-MAIL : sherwinbabbco@orange.fr

TECHNICAL DATA SHEET

Ref : TDS/

N 120 WIPES

Page : 1/3

Rev : 3 Date : 11/09

N 120 WIPES

MANUFACTURER : Babb Co (FR) / SOCOMOR (FR)

DESCRIPTION / APPLICATION(S) :

These N 120 impregnated wipes are an elegant method for cleaning parts, e.g. before penetrant testing, while limiting the quantities of this very powerful solvent released to the atmosphere.

Refer to the N 120 technical datasheet for further details.

Companion products : all penetrants
N 106A remover
R 60, D-100, D-90G developer

SPECIFICATION(S) / STANDARD(S) :

- Conforms to code(s) : ASME, RCC-M
standard(s) : ISO 3452-2
- Homologation : PMUC (French acronym for : Products and Equipments allowed for use in power plants by EDF-French Electricity Board)

PHYSICO-CHEMICAL PROPERTIES:

- Aspect: white wipes impregnated with N 120.
- Very low halogen and sulfur content.

PACKAGING / TRANSPORT / STORAGE :

- **Packaging :** the wipes are shipped in a waterproof envelope (100 wipes per envelope)
- **Transport / Handling :** Refer to Material Safety Data Sheet (MSDS).
- **Storage / Shelf life :** Keep away from moisture
Temperature range : 0°C à 50° C (32°F to 122°F).
Keep packaging closed after taking out some of the product
Non opened envelope : 30 months

TECHNICAL DATA SHEET

Ref : TDS/

N 120 WIPES

Page : 2/3

Rev : 3 Date : 11/09

INSTRUCTIONS :



1. Open the aluminium bag containing pre-impregnated wipes by tearing the upper part of the bag. Do not take out the roll of wipes



2. Unscrew plastic box cap. Put the bag in the box, the opening at the top. Pull the wipe from the center of the roll.



3. Insert the wipe in the slot of the cap.



4. Screw the cap. Pull wipes as you need.



5. A flap assisted by a spring shuts the cap when not in use. Be sure the flap is secured to prevent solvent evaporation



6. Clean surface with the wipes. If a stronger result is looked for, use wipes folded.



7. Used wipes are discarded in a plastic bag. 8. When the roll is finished, unscrew the cap. Throw away the empty bag. Do not throw away the plastic box and cap, they are reusable.





15 rue des Frères Lumière – BP 136
78374 PLAISIR
FRANCE

Tél : 01.30.80.81.98

Fax : 01.30.80.81.99

WEB : www.babbco.fr

E-MAIL : sherwinbabbco@orange.fr

TECHNICAL DATA SHEET

Ref : TDS/

N 120 WIPES

Page : 3/3

Rev : 3 Date : 11/09

Between each use, close the container cap in order to prevent wipes to dry.

Penetrant testing :

Wait for 2 to 3 minutes for N 120 evaporation before applying penetrant.

HEALTH AND SAFETY : Refer to Material Safety Data Sheet (MSDS).

*The information given herein is given in good faith to our customers for the sole purpose of assisting them in the use of the products. The document contains no formal or implicit guarantee regarding its use.
Babb Co cannot be held responsible for damages of any nature resulting from information provided in this document. In addition, none of the information which the document contains should be interpreted as a recommendation for the use of the products which would infringe the protected rights of industrial property.*